


FIGURE 1






FIGURE 3




FIGURE 4




FIGURE 5

FIG. 6




FIGURE 6




FIGURE 7




FIGURE 8







FIGURE 9a



100'

FIGURE 9b




FIGURE 9C




FIGURE 9d





FIGURE 9e



100'

FIGURE 9f




FIGURE 9g




FIGURE 10






FIGURE 11

245'





FIGURE 12

265'






FIGURE 14

FIG. 15 is a flowchart illustrating a method for handling VOQ group methods.




FIGURE 15

FIG. 16




FIGURE 16




FIGURE 17




FIGURE 18




FIGURE 19a






FIGURE 19b




FIGURE 19C




FIGURE 19d




FIGURE 19e




FIGURE 19f




FIGURE 20a




FIGURE 20b





FIGURE 20c





100"

FIGURE 20d




FIGURE 21





FIGURE 22



1345'

FIGURE 23